

SUPPLEMENTAL INSTALL SHEET

Nissan Titan Tonneau Rail Positioning



IMPORTANT: Supplement



Step **2** of the Installation Sheet calls for the positioning of the tonneau rail all the way forward to the bulkhead.

With the Nissan Titan factory accessory rail mounted to the bulkhead, the tonneau rail is required to be positioned back from the bulkhead approximately 1/4" to 1/2".

Install the Drain Tube and push the rails as far forward as possible. Return to Step **3** of the Installation Sheet.

